



Tips on Optimising Interphone Battery Life

CONSUMPTION IN INTERPHONE MODE

In **Interphone mode the battery consumption is higher** than while using the product with mobile phones or GPS navigators.

There are many different reasons for this.

The **battery performance level** depends on:

- 1 **listening volume**
- 2 **the distance between** the two control units (particularly bike-bike)
- 3 **the obstacles between** the two devices during travel (particularly bike-bike)
- 4 **the outside temperature.**

BATTERY PERFORMANCE LEVEL

Because of the variables listed above, Interphone battery performance level can vary in length and function. This does not mean the system is malfunctioning.

Performance in Interphone mode: from 4 to 6 hours

Performance in Speakerphone mode: up to 9 hours

The time of 7 hours shown on the pack is an average performance calculated on varied use.

TIPS

To **optimise** battery performance level, **follow these tips:**

- **When you stop**, remember to deactivate the interphone, **turn off the device** and remove it from your helmet if it is in direct sunlight.
 - When using interphone mode, **open communications only when you want to speak** (turn off when you finish speaking and leave in standby).
 - If there is a lot of background noise or you are travelling fast, **your listening volume increases* automatically**. In this case it is better to slow down while you are having a conversation.
 - **When there is a lot of traffic or you are travelling at high speed**, it is not advisable to talk and better to turn off the device and leave it in standby.
 - When installing the device, **make sure the earphone is in contact with your ear** to avoid loss of sound signal which would force you to raise the volume*.
- (*remember that listening volume affects consumption)

CHARGING THE BATTERIES

As with all mobile electronic devices, to safeguard your batteries and get the best out of them, it is important to remember some simple tips:

- To make your batteries last longer, recharge only when they are fully discharged.
- Recharge for about two hours to ensure complete recharging.
- When using Interphone for the first time, remember that maximum battery charge is reached only after batteries have been completely recharged 2/3 times.
- To use two devices in interphone mode, make sure both are charged.



1. Volume



2. Distance



3. Obstacles



4. Temperature

4/6 Hours



Helmet/Helmet

UP TO 9 Hours



Mobile Phone/Helmet

700 Hours

Stand-by



Exclusive UK distributor:
Moto Comp Ltd

PO Box 3782 Hope Valley S32 3WR

T: 08700 340283 E: interphone@motocomp.com

W: motocomp.com